



BUTLER

Butler Parachute Systems, Inc., P.O. BOX 6098, 1820 Loudon Ave., N.W., Roanoke, VA 24017
540-342-2501 Email: sales@butlerparachutes.com, www.butlerparachutes.com

Sheepskin Care

Your sheepskin is chrome tanned and may be machine washed. However, for most purposes, basic cleaning should require only brushing (a pet brush is ideal) and vacuuming. Severe heat can damage sheepskin, resulting in shrinking and hardening of pelts. Do not use alkaline products to clean sheepskin.

For mild cleaning:

1. Sponge clean with water and a mild detergent.
2. Comb the wool while wet and air-dry skins away from artificial or excessive heat.
3. Skins may tend to crimp after washing. If a straight hair appearance is preferred, brush fleece with a pet brush.

For deeper cleaning:

1. Machine wash in warm water not exceeding 110 degrees F (90 degrees C). Using hotter water may shrink the seat cover
2. Use only pure, mild soap (Ivory soap). **Do not use Woolite.**
3. Comb the wool while wet and air dry skins away from artificial or excessive heat.
4. Skins may tend to crimp after washing. If a straight hair appearance is preferred, brush fleece with a pet brush.

If you spill oil on your sheepskin:

1. Treat the affected area with baby powder. Rub the powder into the area and leave the powder in for three hours.
2. Brush the powder out of the skin with a pet brush.
3. Repeat if necessary.