

# Activating the Capewell Canopy Release



**WARNING**

NEVER RELEASE THE CANOPY WHILE YOU ARE IN THE AIR. ONLY RELEASE THE CANOPY AFTER YOU HAVE LANDED AND ARE ON THE GROUND OR IN THE WATER. RELEASING THE CANOPY WHILE YOU ARE IN THE AIR WILL CAUSE SERIOUS INJURY OR DEATH.



Grab the front cover of the release with your thumb and your index finger.



Pull the cover out and down to expose the cable loop.



Hook your thumb through the cable loop.



Pull the cable loop until the canopy riser releases.